



AIO PRODUCTS UPDATE PROCESS

YOU WILL NEED YOUR AIO AND A COMPUTER CONNECTED TO THE SAME INTERNET NETWORK

1. You need to power the **AIO** and wait for it to connect to your network
2. You need to find the **AIO** IP address (the « address » of your AIO on your network):

- Go to the **TRIANGLE AIO** app, in the « Device list », select the Settings icon ①

- Then select « Speaker Info » ② and note the IP number ③

3. Now you need to use your computer and go to the following update website

<https://bit.ly/2RxW9hY>

4. Enter the IP number that you note in this webpage (Device IP (Required))

5. Once this is done, go to the bottom of the page and select « Do It Now »

6. It will open a new windows, only showing « OK »


7. Go back to the **TRIANGLE AIO** app where you should get a update message or see a red « NEW » icon near your **AIO** name. Select the "NEW"

8. Accept the update and wait for it to finish


9. For **AIO C** and **AIO PRO A50**, the **AIO** will reboot and connect automatically to your network

10. For **AIO 3** : You need to power down the **AIO 3**, wait 10 seconds and power it back ON. If it is connected to your network with an Ethernet cable, **AIO 3** will now be ready to play. If it was connected with Wi-Fi, you will need to do the Wi-Fi configuration.

①



②



③

